

# **IPS Ltd.**

## **TIE BAR COVER APPLICATION NOTES**

- 1] SHINEY SIDE OF COVER SHOULD BE AGAINST TIE BAR.**
- 2] MOUNT MAGNETS TO STRAPS WITH SCREW HEAD INSIDE MAGNET.**
- 3] ASSEMBLE ONTO TIE BAR WITH ZIPPER DOWN AND AWAY FROM MOLD. VELCRO STRAP SHOULD BE AT NON - MOVABLE PLATEN**
- 4] SET TABS WITH MAGNETS ONTO MOVABLE PLATEN.**

## **WARNING!**

**Hot purging will destroy Tie Bar Covers.**

**Standing on Tie Bar Covers is not safe.**